



Family First Enterprises Four Position Baby Carrier

IMPORTANT INFORMATION! KEEP FOR FUTURE REFERENCE INSTRUCTIONS, CARE AND WARNING INFORMATION

Please read the following information pertaining to the use, care and warnings of your baby carrier. Failure to follow the instructions for the use and care could result in serious injury or death. Please read this information before using the different positions.

The carrier's four positions are: Sling, Face In, Face Out, and Backpack

Sling Position:



Remove waist belt for sling position.

Make sure that removable back plate is inserted and secure the neck belt so it is through the hole on the top of the back plate, and that the two buckles are securely snapped onto the two shoulder straps.



Loosen the shoulder straps to the full extent. Put the sling on a stable soft surface; unbuckle the straps that secure the seat plate so that it lies flat and rear panel away from you.



Place baby's back flat on carrier with head at top of the rear panel and pull seat plate up between baby's legs and securely snap into place, tightening to create a secure snug fit.



Adjust shoulder straps to full length before positioning into carry position to make it easier to put straps over your head.

Bring the two shoulder straps together at the point of where the two strap buckles meet, and wrap long strap around other strap and then secure buckle. Tighten the strap to make tight fit, basically making the two straps one to go over your head.



Lift carrier to take up slack of the shoulder straps, sliding the arm opposite baby's head into sling and place over your head and hanging on your shoulder with strap horizontally across your back. Adjust the shoulder straps to tighten and fit securely.



Baby's head should be on the side of your free arm to help cradle baby in sling.

Warning: Take extra care and precautions when bending and / or leaning, as this will affect your balance and could cause injury to you or your child.

Facing in: Use this position until your baby is able to hold their head upright.



Replace the waist belt if it has been removed. Place the belt through the front seat panel loop, placing the buckle in the so that the wide padded area of the strap is in the rear. This allows for maximum comfort and ease of getting to the buckle for adjustment and securing off and on your waist.



Loosen the shoulder straps to the full extent. Put the sling on a stable soft surface; unbuckle the straps that secure the seat plate so that it lies flat and rear panel away from you.



Place baby's back flat on carrier with head at top of the rear panel and pull seat plate up between baby's legs and securely snap into place, tightening to create a secure snug fit.



Lean forward over the baby and put straps through your shoulders and lift yourself up. Buckle the shoulder straps together in the back; adjust the shoulder straps and waist belt for a secure fit.



Warning: Take extra care and precautions when bending and / or leaning, as this will affect your balance and could cause injury to you or your child.

Facing Out: Use this position once your baby is able to hold their head up.



Replace the waist belt if it has been removed. Place the belt through the front seat panel loop, placing the buckle in the so that the wide padded area of the strap is in the rear. This allows for maximum comfort and ease of getting to the buckle for adjustment and securing off and on your waist.



Remove the buckles from the headrest plate, and remove headrest plate by separating it from its secure Velcro fastener and pulling out of the rear panel.



Loosen the shoulders straps to the full extent. Put the sling on a stable soft surface; unbuckle the straps that secure the seat plate so that it lies flat and chest panel is facing away from you.



Place the baby in a sitting position, facing away from you, and bring seat panel up from behind baby securely snapping rear panel buckles in place. Make sure that the front panel supports the baby's chest area.



Lean forward over the baby and put straps through your shoulders and lift yourself up. Buckle the shoulder straps together in the back; adjust the shoulder straps and waist belt for a secure fit.



Warning: Take extra care and precautions when bending and / or leaning, as this will affect your balance and could cause injury to you or your child.

Backpack Position:



Replace the waist belt if it has been removed. Place the belt through the front seat panel loop, placing the buckle in the so that the wide padded area of the strap is in the rear. This allows for maximum comfort and ease of getting to the buckle for adjustment and securing off and on your waist.



Loosen the shoulders straps to the full extent. Put the sling on a stable surface; unbuckle the straps that secure the seat plate so that it lies flat and back panel is facing away from you.



Place the baby in a sitting position, facing toward you, and bring seat panel up from front of baby, securely snapping rear panels buckles in place. Make sure that the rear panel supports the baby's back area.



To ensure maximum safety while loading the carrier in the backpack position, you should use the aid of another person to help you lift and properly position the carrier securely into place before adjusting. An alternate method is to place carrier with baby in a chair and sit or kneel in front, putting your arms through the straps before standing straight up.

Buckle the shoulder straps together in the front; adjust the shoulder straps and waist belt for a secure fit.

Warning: Take extra care and precautions when bending and / or leaning, as this will affect your balance and could cause injury to you or your child.

CARE and WASHING INSTRUCTIONS

Machine wash cold, separately on a gentle cycle.

DO NOT Bleach.

DO NOT tumble dry; Drip dry only.

DO NOT Iron.

DO NOT Dry Clean.

Spills can be wiped clean with a mild cleaning solution between washings.

⚠ WARNINGS!

⚠ WARNING

FALL AND SUFFOCATION HAZARD

FALL HAZARD – Infants can fall through a wide leg opening or out of carrier.

- Adjust leg openings to fit baby's legs snugly.
- Before each use, make sure all straps are secure.
- Take special care when leaning or walking.
- Never bend at waists: bend at knees.
- Only use this carrier for children between 8lb and 29lb.

SUFFOCATION HAZARD – Infants under 4 months can suffocate in this product if face is pressed tight against your body

- Do not strap infant too tight against your body
- Allow room for head movement
- Keep infant's face free from obstructions at all times.

⚠ WARNINGS!

Failure to follow the warnings and instructions for the use of this Baby Carrier can result in serious injury or death!

This carrier is intended to be used by adults while walking or standing only.

- ⚠ DO NOT use this carrier with baby to engage in any sporting activities, driving or as a passenger in a vehicle, or use as a type of restraint in a vehicle.
- ⚠ DO NOT use in any type of water activities; swimming, bath tub, shower, etc.
- ⚠ DO NOT bend over with baby in carrier while wearing; bend at your knees so that baby stays secure in the carrier.
- ⚠ NEVER expose baby and carrier to any source of heat or chemicals that can come in contact you, your baby and carrier.
- ⚠ NEVER leave baby unattended in carrier.

Check and make sure frequently that baby is secure, in an upright position and baby's chin is not pointing down toward chest.

This carrier is subject to normal wear; straps, buckles, fabric and seams should be inspected for excessive wear, tears and / or separation before each use. DO NOT use if carrier is damaged in any way, as this could be unsafe and cause injury or death.

Please keep these instructions to review for future reference.

FAMILY FIRST ENTERPRISES

www.familyfirstenterprises.com

Complies with the safety requirements of ASTM F2236